


SERVICE MANUAL

STEREO POWER AMPLIFIER **SANSUI B-3000/1000**



CAUTION

1. Parts identified by the Δ symbol on the schematic diagram and the parts list are critical for safety. Use only replacement parts that have critical characteristics recommended by the manufacturer.
2. Make leakage-current or resistance measurements to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

•SPECIFICATIONS

< B-3000 >

Power output

Min. RMS, both channels driven, from 20 to 20,000 Hz, with no more than 0.05% total harmonic distortion.

120 watts per channel into 8 ohms

Load impedance 8 to 16 ohms

Intermodulation distortion (70 Hz: 7 kHz = 4:1, SMPTE method) less than 0.01% at rated power output

Frequency response (at 1 watt)

..... 5 to 100,000 Hz,

..... +0 dB, -2 dB

Input sensitivity and impedance (at 1 kHz)

..... 1 V/33 kohms

Signal to noise ratio (short-circuit, A-network)

..... 110 dB

Power requirements AC 120V/220V/240V, 50/60 Hz

For U.S.A. & Canada .. AC 120V, 60 Hz

Power consumption

..... 440 watts 540 VA Rated Dimensions

..... 430 mm (16-15/16") W

..... 127 mm (5") H

..... 224 mm (8-13/16") D

Weight

..... 9.6 kg (21.2 lbs) net

< B-1000 >

Power output

Min. RMS, both channels driven, from 20 to 20,000 Hz, with no more than 0.05% total harmonic distortion.

75 watts per channel into 8 ohms

Load impedance 8 to 16 ohms

Intermodulation distortion (70 Hz: 7 kHz = 4:1, SMPTE method) less than 0.01% at rated power output

Frequency response (at 1 watt)

..... 5 to 100,000 Hz,

..... +0 dB, -2 dB

Input sensitivity and impedance (at 1 kHz)

..... 1 V/33 kohms

Signal to noise ratio (short-circuit, A-network)

..... 110 dB

Power requirements AC 120V/220V/240V, 50/60 Hz

Power consumption

..... 300 watts Dimensions

..... 430 mm (16-15/16") W

..... 127 mm (5") H

..... 224 mm (8-13/16") D

Weight

..... 7.0 kg (15.4 lbs) net

• Design and specifications subject to changes without notice for improvements.

• Due to local laws and regulations, this unit sold in some areas are not equipped with variable voltage selectors.

Sansui

SANSUI ELECTRIC CO., LTD.

NOTE

1. The symbols, UL, CSA, SA, BS, UK, EU, AS, SEV, SS, XX <EXPORT> and XX-V <EXPORT(V)> on the parts list and the schematic diagram mean followings respectively.


UL.....	Manufactured for U.S.A market. (Underwriters Laboratories approved model.)
CSA	Manufactured for Canadian market.
SA.....	Manufactured for South African market.
BS, UK	Manufactured for United Kingdom market.
EU	Manufactured for European market.
AS.....	Manufactured for Australian market.
SEV	Manufactured for Swiss market.
SS.....	Manufactured for Saudi Arabian market.
XX <EXPORT>	Standard Version with Inner Voltage Selector.
XX-V <EXPORT(V)> ..	Standard Version with Outer Voltage Selector.
NON MARK	Common Parts.
2. Some printed circuit boards are not supplied assembled. To separate these in this service manual, the stock numbers are not indicated for these boards. However, stock numbers for individual parts are indicated.
3. Since some capacitors and resistors are omitted from parts lists in this service manual, refer to the Common Parts List for capacitors and resistors, which was issued on February 1983.
4. Abbreviations in this service manual are as follows.

•Abbreviations List


C.R.	: Carbon Resistor	E.B.L.	: Low Leak Bi-Polar
S.R.	: Solid Resistor		Electrolytic Capacitor
Ce.R.	: Cement Resistor	Ta.C.	: Tantalum Capacitor
M.R.	: Metal Film Resistor	F.C.	: Film Capacitor
F.R.	: Fusing Resistor	M.P.	: Metalized Paper Capacitor
N.I.R.	: Non-Inflammable Resistor	P.C.	: Polystyrene Capacitor
A.R.	: Array Resistor	G.C.	: Gimmic Capacitor
C.C.	: Ceramic Capacitor	A.C.	: Array Capacitor
C.T.	: Ceramic Capacitor, Temperature Compensation	V.R.	: Variable Resistor
E.C.	: Electrolytic Capacitor	S.V.R.	: Semi Variable Resistor
E.L.	: Low Leak Electrolytic Capacitor	SW.	: Switch
E.B.	: Bi-Polar Electrolytic Capacitor	Chip R.	: Chip Resistor
		Chip C.	: Chip Capacitor

1. INTERIOR BLOCK DIAGRAM OF IC


• STK3152-3 (Differential Amp.)




• TA7317P (Speaker Protector)



• IR2E29 (L.E.D. Drive)



• M5218P/NJM4558D (OP Amp.)



2. PARTS LIST OF BOARD

2-1. F-5778 Main Amp Board (Stock No. 01045301 = B-3000/01046201 = B-1000)

Parts No.	Stock No.	Description	Parts No.	Stock No.	Description
• Transistor					
△ kQ1	03067401	2SC1845	IQ7	03010901	2SA992
△ kQ2	48263101	2SC3298A <B-3000>			
△	07206401	2SD600K <B-1000>	• IC		
△	or 48849101	2SC3944A <B-3000>	IIC1	46207600	TA7317P
△ kQ3	48263001	2SA1306A <B-3000>	• Diode		
△	07206301	2SB631K <B-1000>	ID1	83000100	1N4148
△	or 48849001	2SA1535A <B-3000>	ID2	83000100	1N4148
△ kQ4	46541401	2SC2921 <B-3000>	ID3	83000100	1N4148
△	48490801	2SC3855 <B-1000>	ID5	83000100	1N4148 <B-3000>
△ kQ5	46541301	2SA1215 <B-3000>	ID6	83000100	1N4148 <B-3000>
△	48490701	2SA1491 <B-1000>	ID7	83005000	1N4002
• IC					
kIC1	48127000	STK3152-3 <B-3000>	IP1	48262800	Thermistor ZPP221C501A110
	48904300	STK3082-2A <B-1000>	△ IPT2	48262700	Thermistor ZPP220T501A80
kIC2	03607700	NJM4558D	IC2	48101500	100μF 6.3V E.B.
	or 46580100	M5218P			
△ kR9	46228400	33Ω 1/2W N.I.R.	△ IR14	46229000	100Ω 1/2W N.I.R.
△ kR12	46228600	47Ω 1/2W N.I.R.	△ IR15	46229000	100Ω 1/2W N.I.R.
△ kR13	46228600	47Ω 1/2W N.I.R.	△ IR16	46229300	180Ω 1/2W N.I.R. <B-3000>
△ kR16	48197000	0.22Ω + 0.22Ω 7W Ce.R. <B-3000>	△	46229100	120Ω 1/2W N.I.R. <B-1000>
△	46184100	0.22Ω + 0.22Ω 5W Ce.R. <B-1000>	△ IR17	46229300	180Ω 1/2W N.I.R. <B-3000>
△ kR17	46623100	10Ω 2W N.I.R.	△	46229100	120Ω 1/2W N.I.R. <B-1000>
△ kR23	46622300	2.2Ω 2W N.I.R.	△ IR23	46249100	120Ω 1/2W N.I.R. <B-3000>
△ kR51	46624700	220Ω 2W N.I.R.	△ IR24	46249100	120Ω 1/2W N.I.R. <B-3000>
			△ IR28	46229100	120Ω 1/2W N.I.R.
			△ IR29	46227400	4.7Ω 1/2W N.I.R.
			IRL1	48524300	Relay, (DC 12V)
				or 48524400	Relay, (DC 12V)
			• Transistor		
			△ mQ1	46614101	2SC3243
			△ mQ2	46614001	2SA1283
			• Diode		
			△ mD2	83004800	KBP02
			• Zener Diode		
			mDZ1	46113900	05Z12-Y
				or 46114000	05Z12-Z
			mDZ2	46113900	05Z12-Y
				or 46114000	05Z12-Z
			△ nR6	46230300	1.2kΩ 1/2W N.I.R.
			oS1	83004700	Push SW., SPEAKERS
			oJ1	83002600	Jack, PHONES
			oZ1	83003900	2P Terminal, INPUT

2-2. F-5779 Power Supply Board

Parts No.	Stock No.	Description
•Diode △mD1	83020900	KBPC802
△mR1	46626600	8.2kΩ 2W N.I.R.
△mR2	46626600	8.2kΩ 2W N.I.R.
△mR3	46622700	4.7Ω 2W N.I.R.
mC1	48846000	8200μF 80V E.C.
mC2	48846000	8200μF 80V E.C.
mC12	08680400	0.01μF 500V C.C.

2-3. F-5780 Speakers Terminal Board

Parts No.	Stock No.	Description
oZ2	83002300	8P Terminal, Speaker

2-4. F-5781 Meter Range SW., Board

Parts No.	Stock No.	Description
oS2	83004500	Push SW., METER RANGE

2-5. F-5782 Indicator Board

Parts No.	Stock No.	Description
•LED nLD9	48849300	SEL3913K, POWER

2-6. F-5784 Fuse Board

Parts No.	Stock No.	Description
△pF1	83022000	Fuse 4A <B-3000> (XX-V-SS)
	83029100	Fuse 8A <B-3000> (UL.CSA)
△	83021800	Fuse 2.5A <B-1000> (XX-V-SS)
△pF2	83022000	Fuse 4A <B-3000> (XX-V-SS)
△	83021800	Fuse 2.5A <B-1000> (XX-V-SS)


2-7. F-5783 Power Level Meter Board

(Stock No. 01045801)


Parts No.	Stock No.	Description
•IC nIC1	46398400	IR2E29
•Zener Diode nDZ1	46109300 or 46109400	05Z3.0-X 05Z3.0-Y
•LED nLD1	48841300	SEL3813A
nLD2	48841300	SEL3813A
nLD3	48841300	SEL3813A
nLD4	48841300	SEL3813A
nLD5	48841300	SEL3813A
nLD6	48841300	SEL3813A
nLD7	48841300	SEL3813A
nLD8	48841300	SEL3813A

3. OTHER PARTS

- Front View



- Top View



4. ADJUSTMENTS

• Parts List <Front View>

Parts No.	Stock No.	Description
1	84503900	Bonnet
2	37500101	Front Panel Ass'y <B-1000>
	37500001	Front Panel Ass'y <B-3000> (XX)
	37500002	Front Panel Ass'y <B-3000> (UL.CSA)
3	83002600	Jack, PHONES
4	48508800	Knob, METER RANGE
5	83004500	Push SW., METER RANGE
6	84508900	Knob, SPEAKERS
7	83004700	Push SW., SPEAKERS
8	84517800	Knob, POWER
△ 9	48113300	Push SW., POWER <B-1000>
△ 10	46612900	Push SW., POWER <B-3000>
10	84505100	Spring, POWER
△ 11	46425800	0.01μF 400V C.C.
12	84527700	Leg

• Notes

1. Room Temperature 18°C ~ 28°C.
2. For this adjustment run the unit for more than 5minutes after the power is switched ON.
3. For the point of adjustment, see the Top View.
4. See Top View on page 5 adjustment position.

STEP	MEASURE OUTPUT	ADJUST	ADJUST FOR
1 L-CH	Terminal (TP) Between emitters of Power transistors (KQ4 & KQ5)	KVR1 (F-5778) L-CH	5mV ±1mV
2 R-CH	Terminal (TP) Between emitters of Power transistors (KQ4 & KQ5)	KVR1 (F-5778) R-CH	5mV ±1mV


Parts List <Top View>

Parts No.	Stock No.	Description
1	84512000	Side Panel, Left <B-3000/1000>
	84519800	Side Panel, Left (UL.CSA) <B-3000>
2	84514000	AC Cord Holder
△ 3	83020000	Power Supply Cord (XX-V•SS)
△ 4	83003600	Power Supply Cord (UL.CSA) <B-3000>
△ 5	48837700	Power Supply Cord (SS)
△ 6	83004100	AC Outlet (XX-V•SS)
△ 7	83002200	AC Outlet-Polarized (XX-V•SS)
△ 8	83002200	AC Outlet (UL) <B-3000>
△ 9	83011509	Power Transformer with VOLTAGE SELECTOR Socket (XX-V•SS)
△ 10	83011602	Power Transformer (UL.CSA) <B-3000>
11	48175200	Plug, VOLTAGE SELECTOR (XX-V•SS)
12	83002300	8P Terminal, SPEAKERS
13	84507500	HS Cover <B-3000>
14	83003900	2P Terminal, INPUT
15	84512100	Side Panel, Right <B-3000/1000>
16	84519900	Side Panel, Right (UL.CSA) <B-3000>
17	07255000	Fan <B-3000>
18	83020800	DC Motor <B-3000>

5. PARTS LOCATION ON BOARD


5-1. F-5784 Fuse Board

Component Side




5-2. F-5779 Power Supply Board

Component Side



5-7. F-5778 Main Amp Board

Component Side



A

B

C

D


E

F

G

H

6. SCHEMATIC DIAGRAM 6-1. B-3000



* Design and specifications subject to change without notice for improvement.
 * La présentation et les spécifications sont susceptibles d'être modifiées sans préavis par suites d'améliorations éventuelles.
 * Änderungen, die dem technischen Fortschritt dienen, bleiben vorbehalten.

SYMBOL
 △ Ceramic
 (B.P) Bi-Polar Electrolytic
 @ (m) Mylar
 □ Non-Inflammable Resistor
 □ Cement Resistor

RESISTORS
 Are in ohms, 1/4 Watts, $\pm 5\%$ Tolerance
 Unless Otherwise Noted, k: k Ω , M: M Ω

CAPACITORS
 Are in μ F, Unless Otherwise Noted, P: μ F

Electrolytic Capacitor
 Capacitance (μ F) / Volt (V)







Each D.C. Voltage shows the nominal value
 in volts at no input signal
 during recording

! is Safety Part.
 Use only replacement parts
 recommended by the manufacturer

SYMBOL OF FUNCTION
 (k) POWER AMP
 (n) INDICATOR
 (m) POWER SUPPLY
 (o) SELECTOR
 (p) FIXED PARTS
 (l) PROTECTOR

SYSTEM A
 oS1e-h I. OFF 2. ON
SYSTEM B
 oS1o-d I. OFF 2. ON
METER RANGE
 oS2o,b I. x1 2. x10

2SA992 2SA1306
 2SA1248 2SA1306A
 2SA1283 2SC3298A
 2SA1284 2SC3944A
 2SC1845 2SC2857



k01 2SC1815(F)
 k02 2SC3298A(O,Y)
 k03 2SA1306A(O,Y)
 k04 2SC2921(O,Y)
 k05 2SA1215(O,Y)
 k1C1 STK3152-3
 k1C2 M5216P
 k1C3 NJM4558D
RF-501T I2620
 l02 2SC1740S(R,S)
 l03 2SC2603(E,F)
 l04 2SC2458(Y,GR)
 l05 2SA1115(E,F)
 l06 2SA1048(Y,GR)
 l07 2SA933S(R,S)
 l08 2SA1248(C,D,E)
 l09 2SC1473(Q,R), 2SC2857(D,E)
 l10 2SA992(F,E)
 lD1,2 1S1588
 lD3 1S2473
 lD4 1N4148
 lD7 1N4002
 lC1 TA7317P
 lP1 ZPP221C501A110
 lP2 ZPP220T501A80
 lR1 DH12D2-05 12V
 lG1 G5R-2282P 12V

— Signal Line
 - - - N.F.B. Line

1

2


3

4

5

A **B** **C** **D** **E** **F** **G** **H**

6-2. B-1000



• Design and specifications subject to change without notice for improvement.
 • La présentation et les spécifications sont susceptibles d'être modifiées sans préavis par suites d'améliorations éventuelles.
 • Änderungen, die dem technischen Fortschritt dienen, bleiben vorbehalten.

SYMBOL OF FUNCTION

- (k) POWER AMP
- (n) INDICATOR
- (m) POWER SUPPLY
- (o) SELECTOR
- (p) FIXED PARTS
- (l) PROTECTOR

SYMBOL
 △ Ceramic
 (B.P.) Bi-Polar Electrolytic
 (Mylar) Mylar
 □ Non-Inflammable Resistor
 □ Cement Resistor

RESISTORS
 Are in ohms, 1/4 Watts, ± 5% Tolerance
 Unless Otherwise Noted. k. kΩ, M. MΩ

CAPACITORS
 Are in pF, Unless Otherwise Noted. P. pF

Electrolytic Capacitor
 Capacitance (pF) / Volt (V)


Each DC Voltage shows the nominal value
 in volts at no input signal
 during recording

SYSTEM A
 o51e-h 1. OFF 2. ON


SYSTEM B
 o51o-d 1. OFF 2. ON

METER RANGE
 o52a,b 1. x1 2. x10

2SA992 2SA1306
 2SA1248 2SA1306A
 2SA1283 2SC3298A
 2SA1284 2SC3944A
 2SC1845 2SC2857



2SC3855 2SA1491
 2SC2458



2SC2921 2SA1215



2SA933 TA7317P



2SC1845(F)
 2SD600K(E,F)
 2SB631K(E,F)
 2SC5855(P,Y)
 2SA1491(P,Y)

STK3082-3
 M5218P
 NJM4558D

k01 2SC1845(F)
 k02 2SD600K(E,F)
 k03 2SB631K(E,F)
 k04 2SC5855(P,Y)
 k05 2SA1491(P,Y)
 k1C1 STK3082-3
 k1C2 M5218P
 k1C3 NJM4558D

k02 2SC1740S(R,S,E)
 2SC2603(E,F)

k03 2SC2458(Y,GR)

2SA1115(E,F)

k03,4 2SA1048(Y,GR)

2SA933S(R,S,E)

k06 2SC2857(D,E,F), 2SC1473(Q,R)

2SA992(F,E)

k07 IS1588
 IS2473
 IN4148

k07 IN4002

k1C1 TA7317P

zRL1 DH12D2-OS 12V
 G5R-2282P 12V

m01 KBP602

m02 KBP02

m01 2SC3243(D,E)

m02 2SA1283(D,E)


m02,12 05Z12(Y,Z)

n1C1 IR2E29

n02,1 05Z3.0(X,Y)

nLD1-9 SEL3813A

1R2E29
 MS218P
 NJM4558D



1S1588
 1S2473
 1N4002
 1N4148



KBPC802
 05Z3.0
 05Z12



Signal Line

N.F.B. Line

1

2

3

4

5

10

7. MAIN PARTS REPLACEMENT

A. Bonnet (Fig. 7-1)

- 1) Loosen two Screws (SA) fixing the Bonnet.
- 2) Lift up the Bonnet to remove.

B. Bottom Plate (Fig. 7-2)

- 1) Loosen Screws (SB) fixing the Bottom Plate.
- 2) Lift up the Bottom to remove.

C. Side Panel, Left (Right) (Fig. 7-3)

- 1) Remove the bonnet and Bottom Plate.
- 2) Shift the position of the Side Panel 2.0cm in the arrow direction (1).
- 3) Remove the hooks of side panel from front panel and them pull it in the arrow direction (3) to the Side Panel Left (Right).
- 4) Lift up PCB guide (X) of the Front Panel Assy to pull out the PCB (Fig. 7-4).

Fig. 7-1




Fig. 7-2




Fig. 7-3





Fig. 7-4




8. PACKING LIST

Parts No.	Stock No.	Description
1	84521900	Styrofoam Packing (Back)
2	84519200	Vinyl Bag
3	84520700	Carton Case <B-1000>
4	84520500	Carton Case <B-3000>
	84522000	Styrofoam Packing (Front)

9. ACCESSORY LIST

Stock No.	Description
49026600	Operating Instruction < B-1000 >
49026700	Operating Instruction < B-3000 >



SANSUI ELECTRIC CO., LTD.
SANSUI ELECTRONICS CORPORATION
SANSUI ELECTRONICS (U.K.) LTD.
SANSUI ELECTRONICS G.M.B.H.

Sansui

14-1, Izumi 2-chome, Suginami-ku, Tokyo 168 Japan
PHONE: (03) 324-8891/TELEX: 232-2076 (International Division)
1250 Valley Brook Ave, Lyndhurst, NJ 07071 U.S.A.
17150 South Margay Ave, Carson, California 90748 U.S.A.
3036 Koapaka Street, Honolulu, Hawaii 96819 U.S.A.
Unit 10A, Lyon Industrial Estate, Rockware Avenue, Greenford, Middx UB6, QAA, England
Paul Erich Strasse 8, 6074 Rödermark-2, West Germany



SERVICE MANUAL

SUPPLEMENT EDITION

B-1000

B-3000

STEREO POWER AMPLIFIER

NOTE

This edition is supplement for B-3000/1000 Service Manual previously issued, and applies to all B-3000 and B-1000 with NEW SANSUI MARK on the front panel. For servicing, please refer to this edition together with original B-3000/1000 Service Manual.

NOTICE:

Since the circuits of motor drive control and protector section employed in B-1000 (CSA-EU and SEV) are similar to those of B-3000, the schematic diagram of those circuits are omitted from this manual, therefore please refer to the schematic diagram of B-3000.

CAUTION

1. Parts identified by the Δ symbol on the schematic diagram and the parts list are critical for safety. Use only replacement parts that have critical characteristics recommended by the manufacturer.
2. Make leakage-current or resistance measurements to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

NOTICE:

1. The symbols, UL, CSA, SS, EU, SEV and XX (EXPORT) on the parts list mean followings respectively.
UL Manufactured for U.S.A market. (Underwriters Laboratories approved model)
CSA Manufactured for Canadian market. SS Manufactured for Saudi Arabia market.
EU Manufactured for European market. SEV Manufactured for Swiss market.
XX (EXPORT) Standard Version. NON MARK Common Parts.

2. On the parts list, the changed parts are specified by "#" mark on top of the Parts No.

I. OTHER PARTS

Parts List <Top View>

Parts No.	Stock No.	Description
1	84512000	Side Panel,Left for B-1000
	84512000	Side Panel,Left for B-3000 (XX-CSA-SS)
	84519800	Side Panel,Left for B-3000 (UL)
2	84514000	AC Cord Holder
△ # 3	83001800	Power Supply Cord for B-1000 (XX)
△ #	83020000	Power Supply Cord-polarized (XX-CSA)
△	83003600	Power Supply Cord for B-3000 (UL)
△ #	83000600	Power Supply Cord for B-1000 (EU-SEV)
△	48837700	Power Supply Cord (SS)
△ 4	83004100	AC Outlet (XX-SS)
△	83002200	AC Outlet-polarized (XX-UL-CSA)
△ 5	83011509	Power Transformer for B-1000 (XX-SS)
△ #	83011503	Power Transformer for B-1000 (CSA)
△ #	83046905	Power Transformer for B-1000 (EU-SEV)
△	83011609	Power Transformer for B-3000 (XX-SS)
△	83011602	Power Transformer for B-3000 (UL-CSA)
△ 6	48175200	Plug,voltage selector(XX-SS)
7	83002300	8P Terminal,SPEAKERS
8	84507500	HS Cover for B-1000 (CSA-EU-SEV)
	84507500	HS Cover for B-3000
9	83003900	2P Terminal,INPUT
10	84512100	Side Panel,Right for B-1000
	84512100	Side Panel,Right for B-3000 (XX-SS-CSA)
	84519900	Side Panel,Right for B-3000 (UL)
11	07255000	Fan for B-1000 (CSA-EU-SEV)
	07255000	Fan for B-3000
12	83020800	DC Motor for B-1000 (CSA-EU-SEV)
	83020800	DC Motor for B-3000
	47878000	Sleeve,Fan for B-1000 (CSA-EU-SEV)
	47878000	Sleeve,Fan for B-3000

Parts List <Front View>

Parts No.	Stock No.	Description
1	84503900	Bonnet
# 2	37503201	Front Panel Ass'y for B-1000
#	37503101	Front Panel Ass'y for B-3000 (XX-SS)
#	37503102	Front Panel Ass'y for B-3000 (UL-CSA)
3	83002600	Jack,PHONES
4	84508800	Knob,METER RENGE
5	83004500	Push SW,METER RENGE
6	84508900	Knob,SPEAKERS
7	83004700	Push SW.,SPEAKERS
# 8	84567000	Knob,POWER
△ 9	48113300	Push SW.,POWER for B-1000
△	46612900	Push SW.,POWER for B-3000
10	84505100	Spring,POWER
△ #11	46425800	0.01μF 400V C.C.
12	84527700	Leg

2. PACKING LIST

Parts No.	Stock No.	Description
1	84521900	Styrofoam Packing (Front)
2	84519200	Vinyl Bag
# 3	84560400	Carton Case for B-1000
#	84560300	Carton Case for B-3000
4	84522000	Styrofoam Packing (Rear)

3. ACCESSORY LIST

Stock No.	Description
# 84453100	Operating Instruction for B-1000 (E.F.S.I)
# 84453200	Operating Instruction for B-1000 (G.Sw)
# 84452800	Operating Instruction for B-3000

E,F,S,I; English, French, Spanish and Italian Version

G,Sw ; German and Swedish Version



SANSUI ELECTRIC CO., LTD..

SANSUI ELECTRONICS CORPORATION:

SANSUI ELECTRONICS G.M.B.H.:

14-1, Izumi 2-chome, Suginami-ku, Tokyo 168 Japan

PHONE: (03) 324-8891/TELEX: 232-2076 (International Division)

1250 Valley Brook Ave. Lyndhurst, N.J. 07071 U.S.A.

17150 South Margay Ave. Carson, California 90746 U.S.A.

3036 Koapaka Street, Honolulu, Hawaii 96819 U.S.A.

Paul Ehrlich Strasse 8, 6074 Roddermark 2, West Germany

山水電氣株式会社

東京都杉並区和泉2-14-1(〒168)